

# 7002 E PRO-SERIES ALARM/KEYLESS ENTRY INSTALLATION DIAGRAM:

This is a **BASIC INSTALLATION** Diagram with the least number of wires needed for just the Keyless Entry install. The needed wires will be marked in **RED** all other wires can be taped up and not used.

