

CONNECTING the 773 STARTER IMMOBLIZER (Starter Kill) to the IGNITION SWITCH HARNESS.

EXAMPLE: GM Ignition Harness

