

# 791P BYPASS MODULE INSTALLATION DIAGRAM: for PASSLOCK 2 on GM Vehicles

This is a BASIC Installtion Diagram used when Installing the 791 Bypass Module to GM's PASSLOCK2 Anti-theft System. The wires that are needed for this Installation are marked in **RED** in this diagram, all others to be taped up and do not use.

