

# 791P BYPASS MODULE INSTALLATION DIAGRAM: for VATS/PASSKEY on GM Vehicles.

This is a BASIC Installtion Diagram used when Installing the 791 Bypass Module to GM's VATS/PASSKEY Anti-theft System. The wires that are needed for this Installation are marked in **RED** in this diagram, all others to be taped up and do not use.

