



T-Harness Installation

Models

#BDT-2080

#BDT-2220

#BDT-2071

- Step 1: Remove the trim panel below the steering column and knee bolster (if equipped) behind trim panel.
- Step 2: Locate the **BLACK** multi-pin connector mounted to the underside of the steering column.
- Step 3: Loosen the 7mm (9/32 sae) bolt locking the two (2) connectors together and pull them apart to separate.
- Step 4: Install the T-harness between the now loose OEM connectors.
- Step 5: Route the T-harness so that it does not interfere with any moving functions of the vehicle.
- Step 6: Thread and tighten the locking bolt on both the T-harness and the OEM harness.
- Step 7: Test all functions of the vehicle to make sure that all operations work according to OEM requirements.
- Step 8: Plug in the Remote Starter/Alarm module to the T-harness.
- Step 9: Test all functions of the Remote Starter/Alarm module and then secure the module into place with nylon tie straps.
- Step 10: Replace all panels in reverse order of removal.