


NEGATIVE TRUNK output Using #775 Relay to:

NOTE ** If you unit has a DIP SWITCH, make sure this DIP SWITCH is set for a (-) Negative output when connecting to the 775 Relay:

(+) Trunk Pop

TRUNK POP wire in vehicle



(-) Trunk Pop

TRUNK POP wire in vehicle

