

DELUXE 200 H4 Harness:

This DIAGRAM is used for BASIC INSTALLATION of REMOTE START FUNCTIONS ONLY!!!

This diagram gives the wire colors on the H4 9-PIN WHITE Harness on the DELUXE 200 that are necessary for the Connections AND Operation for REMOTE STARTING ONLY! and are marked in RED all other are not needed:

H4 9-PIN WHITE Harness

H4/1	VIOLET/WHITE	Tach Input wire
H4/2	THIN BLACK	(-) Neutral Safety Switch & (-) Remote Start Toggle Switch Input (this wire if not connected to a Remote Start Toggle Switch Must be connected to Body Ground)
H4/3	BROWN/RED	(+) Positive Safety Shutdown for Brake
H4/4	GRAY	(-) Negative Safety Shut Down for Hood Pin Switch
H4/5	RED/WHITE	(-) 200mA Channel 3 (Trunk) Output (Requires Part #775 Relay)
H4/6	BROWN/BLACK	Factory Security Rearm Signal Output (Factory Default setting) (-) 200mA Programmable Output or (-) Ground Output during Start (Crank)
H4/7	BLACK/WHITE	(-) 200mA Domelight Supervision Output (Requires Part #775 Relay)
H4/8	LIGHT GREEN/BLACK	Dual Pulse Door Unlock Output (Factory Default Setting) (-) 200mA Programmable Output or Factory Security Disarm Signal output or Start Status (Shock Sensor Bypass Control) Output
H4/9	BLUE/BLACK	(-) 200 mA Ignition 3 Control Output (See NOTE * Below)



IMPORTANT NOTE: Directly connect the H4/2 THIN BLACK wire to Ground when this wire is NOT USED for either of the above connections.

NOTE * the H4/9 BLUE/BLACK wire is ONLY used when Installing a SECURITY BYPASS MODULE and is only needed if the vehicle is equipped with an ANTI-THEFT System.