


# Parking Light and Brake isolation diagram for RS-1100/114, RS-1200, and RS-1300E...



**NOTE\*\*\*\*** if parking light wire is a (+) positive connect the **BLUE** to constant 12 volts, if the parking light wire is (-) negative connect the **BLUE** to **GROUND**.....

## BRAKE LIGHT ISOLATION

