

RS-602E/RSA-602E INSTALLATION DIAGRAM

This Diagram is a BASIC INSTALLATION Diagram used ONLY for the Basic Installation of the REMOTE STARTER Section. The Wires and Harnesses below will be marked in RED and are NECESSARY for the installing of the REMOTE STARTER ONLY! All other are not necessary and can be taped up and not used!.

INSTALLATION DIAGRAM

