



T-Harness Installation

Models
HON-2
HON-1

- Step 1: Remove the trim panel below the steering column and knee bolster (if equipped) behind trim panel.
- Step 2: Locate the factory ignition harness at the fuse panel under the driver's side dash and unplug.
- Step 3: Plug the T-harness in between the factory ignition harness.
- Step 4: Route the T-harness so that it does not interfere with any moving functions of the vehicle.
- Step 5: Test all functions of the vehicle to make sure that all operations work according to OEM requirements.
- Step 6: Plug in the Remote Starter/Alarm module to the T-harness.
- Step 7: Test all functions of the Remote Starter/Alarm module and then secure the module into place with nylon tie straps.
- Step 8: Replace all panels in reverse order of removal.