



T-Harness Installation

Models #BDT-2030

- Step 1: Remove the trim panel below the steering column and knee bolster (if equipped) behind trim panel.
- Step 2: Locate the factory ignition harness at the steering column and unplug.
- Step 3: To unplug factory harness, you must first unplug the black harness then the blue harness.
- Step 4: Plug the T-harness in between the factory ignition harness, first blue harness then black.
- Step 5: Route the T-Harness so that it does not interfere with any moving functions of the vehicle.
- Step 6: Test all functions of the vehicle to make sure that all operations work according to OEM requirements.
- Step 7: Plug in the Remote Starter/Alarm module to the T-Harness.
- Step 8: Test all functions of the Remote Starter/Alarm module and then secure the module into place with nylon tie straps.
- Step 9: Replace all panels in reverse order of removal.